

ALLIANCE TECH TIP: UNDERSTANDING YOUR TV SYSTEM

Updated: 11.19.21

COAX LINE KEY

SATELLITE

ANTENNA

CABLE/OVER-THE-AIR

■■ CUSTOMER SUPPLIED

SATELLITE TV

- 1. Connect coax line from Satellite Dish to "SAT" input on front of Utility Panel.
- 2. Connect one of the Unconnected Satellite Lines (for desired TV) to backside of "SAT" input on Water Utility Panel. (Note: These satellite lines were left unconnected intentionally by the factory, so you can choose which TV you want to connect to the satellite. To connect multiple TVs with satellite an aftermarket SWM or multi-switch will be required)
- 3. Connect Satellite Receiver to Wall Plate (coax cable) and TV (HDMI cable) per satellite providers instructions.
- 4. Utilize television remote control to select satellite input on the TV.

OVER-THE-AIR & CABLE TV

- Over-The-Air

 —Turn "ON" green LED located on the Booster Switch
- <u>Cable</u>—Connect cable from the park to the "CABLE" input on Utility Panel, and turn "OFF" green LED located on the Booster Switch.

