




PARTS LIST

N15DC SERIES
N20DC SERIES

PART NO.641044
NORCOLD 5/10/2022

DOOR - UPPER RIGHT (FRESH FOOD) - N15DC AND N20DC SERIES




NO.	PART #	DESCRIPTION	N15DCSS	N15DCIMSS	N20DCSS	N20DCIMSS
1	640965	KIT RIGHT CABINET DOOR ASSEMBLY (USE 641038)	X	X		
	641038	KIT RIGHT CABINET DOOR ASSEMBLY	X	X		
	641061	KIT RIGHT CABINET DOOR ASSEMBLY (USE 641165)			X	X
	641165	KIT RIGHT CABINET DOOR ASSEMBLY			X	X
2	640964	CONTROL PANEL	X	X	X	X
3	640963	PANEL COVER	X	X	X	X
4	640973	DOOR LATCH CABLE ASSEMBLY	X	X	X	X
5	640975	LATCH ASSEMBLY	X	X	X	X
6	640958	DOOR SENSOR (MAGNET)	X	X	X	X
7	640969	HANDLE LED	X	X	X	X
8	640970	HANDLE LED COVER	X	X	X	X
9	640972	HANDLE ASSEMBLY	X	X	X	X
10	640674	HANDLE COVER	X	X	X	X
11	640978	LATCH COVER	X	X	X	X
12	640977	RIGHT DOOR STOPPER	X	X	X	X
13	640966	FRESH FOOD DOOR GASKET	X	X		
	641063	DOOR GASKET , FRESH FOOD			X	X
14	640979	DOOR FOAM PLUG	X	X	X	X
15	640971	HANDLE LED COVER LOWER	X	X	X	X
16	640968	DOOR BIN	X	X		
NS	641091	FREEZER LIGHT	X	X	X	X

NS NOT SHOWN

NO LONGER AVAILABLE

DOOR - UPPER LEFT (FRESH FOOD) - N15DC AND N20DC SERIES



DOOR - UPPER LEFT (FRESH FOOD) - N15DC AND N20DC SERIES


NO.	PART #	DESCRIPTION	N15DCSS	N15DCIMSS	N20DCSS	N20DCIMSS
1	640967	KIT - LEFT CABINET DOOR ASSEMBLY (USE 641039)	X	X		
	641039	KIT - LEFT CABINET DOOR ASSEMBLY	X	X		
	641062	KIT - LEFT CABINET DOOR ASSEMBLY (USE 641166)			X	X
	641166	KIT - LEFT CABINET DOOR ASSEMBLY			X	X
2	640990	LOGO	X	X	X	X
3	640973	DOOR LATCH CABLE ASSEMBLY	X	X	X	X
4	640975	LATCH ASSEMBLY	X	X	X	X
5	640958	DOOR SENSOR (MAGNET)	X	X	X	X
6	640969	HANDLE LED	X	X	X	X
7	640970	HANDLE LED COVER	X	X	X	X
8	640972	HANDLE ASSEMBLY	X	X	X	X
9	640674	HANDLE COVER	X	X	X	X
10	640978	LATCH COVER	X	X	X	X
11	640976	LEFT DOOR STOPPER	X	X	X	X
12	640966	FRESH FOOD DOOR GASKET	X	X		
	641063	DOOR GASKET FRESH FOOD			X	X
13	640979	DOOR FOAM PLUG	X	X	X	X
14	640968	DOOR BIN	X	X		
	641064	DOOR BIN			X	X
15	640971	HANDLE LED COVER LOWER	X	X	X	X
16	640980	FLAPPER ASSEMBLY	X	X		
	641040	KIT - FLAPPER ASSEMBLY	X	X		
	641065	FLAPPER ASSEMBLY			X	X
	641167	KIT - FLAPPER ASSEMBLY			X	X
NS	641091	FREEZER LIGHT	X	X	X	X

NS

NOT SHOWN

NO LONGER AVAILABLE

FREEZER DRAWER ASSEMBLY - N15DC AND N20DC SERIES



ART 02788

NO.	PART #	DESCRIPTION	N15DCSS	N15DCIMSS	N20DCSS	N20DCIMSS
1	640981	FREEZER DOOR	X	X		
	641067	FREEZER DOOR			X	X
2	640956	FREEZER BRACKET-LEFT	X	X	X	X
3	640957	FREEZER BRACKET-RIGHT	X	X	X	X
4	640955	FREEZER WIRE BASKET	X	X		
	641060	WIRE FREEZER BIN			X	X
5	640945	FREEZER SLIDE	X	X	X	X
6	640948	FREEZER GUIDE RAIL-LEFT	X	X	X	X
7	640949	FREEZER GUIDE RAIL- RIGHT	X	X	X	X
8	640950	FREEZER BIN UPPER	X	X		
	641041	KIT - FREEZER BIN UPPER	X	X		
	641059	UPPER FREEZER BIN			X	X
	641168	KIT - UPPER FREEZER BIN			X	X
9	640953	UPPER BIN FREEZER WHEEL FRONT	X	X	X	X
10	640952	UPPER BIN FREEZER WHEEL REAR	X	X	X	X
11	640954	ICE BIN	X	X	X	X
12	640951	BIN RESTRAINT	X	X	X	X
13	640983	HANDLE ASSEMBLY	X	X	X	X
NS	640982	FREEZER DOOR GASKET	X	X		
	641066	FREEZER DOOR GASKET			X	X
NS	641098	FREEZER BIN DIVIDER			X	X


NS

NOT SHOWN



NO LONGER AVAILABLE

CABINET ASSEMBLY (FRONT VIEW) - N15DC AND N20DC SERIES



ART 02789

CABINET ASSYMBLY (FRONT VIEW) - N15DC AND N20DC SERIES


NO.	PART #	DESCRIPTION	N15DCSS	N15DCIMSS	N20DCSS	N20DCIMSS
1	640928	INTERNAL FAN COVER	X	X	X	X
2	640927	INTERNAL FAN	X	X	X	X
	641042	KIT - INTERNAL FAN	X	X	X	X
3	640929	INTERNAL FAN HOUSING	X	X	X	X
4	640933	LIGHT ASSEMBLY	X	X	X	X
5	640925	VENT MOUNTING BRACKET	X	X	X	X
6	640932	FLAPPER GUIDE	X	X	X	X
7	640960	WIRE COVER	X	X	X	X
8	640984	CONTROL BOARD	X	X	X	X
	641043	KIT- CONTROL BOARD	X	X	X	X
9	640924	MAGNET DOOR SENSOR	X	X	X	X
10	640940	UPPER LEFT HINGE	X	X	X	X
11	640926	VENT	X	X		
	641054	TOP VENT			X	X
12	641032	VENT HOLE PLUG	X	X	X	X
13	640941	UPPER RIGHT HINGE	X	X		
14	640935	REAR SLIDE OUT SHELF	X	X		
	641056	SLIDE OUT SHELF REAR			X	X
15	640936	FRONT SLIDE OUT SHELF	X	X		
	641057	SLIDE OUT SHELF FRONT			X	X
16	640934	FRESH FOOD SHELF	X	X		
	641055	FRESH FOOD SHELF			X	X
17	640937	CRISPER BIN	X	X		
	641058	CRISPER BIN			X	X
18	640149	THERMOSTAT AND COVER	X	X	X	X
19	640939	CENTER HINGE - RIGHT	X	X	X	X
20	640947	UPPER FREEZER DRAWER MOUNT- RIGHT	X	X	X	X
21	640944	LOWER FREEZER DRAWER MOUNT- RIGHT	X	X	X	X
22	640942	LATCH PLATE	X	X	X	X
23	640938	CENTER HINGE LEFT	X	X	X	X
24	640946	UPPER FREEZER DRAWER MOUNT- LEFT	X	X	X	X
25	640943	LOWER FREEZER DRAWER MOUNT- LEFT	X	X	X	X
26	640959	BOTTOM WIRE COVER	X	X	X	X
27	640988	DOOR SENSOR-FREEZER	X	X	X	X
28	640962	FOOT	X	X	X	X
29	641036	FUSE HOUSING	X	X	X	X
30	641037	FUSE WIRE COVER	X	X	X	X
31	641033	ICE MAKER		X		X
32	641034	ICE MAKER FITTING		X		X
33	641035	WATER VALVE		X		X
NS	641096	SHELF DIVIDER			X	X
NS	641097	CRIPSER DIVIDER			X	X

NS

NOT SHOWN

NO LONGER AVAILABLE

CABINET ASSY (REAR VIEW) - N15DC AND N20DC SERIES



ART 02790

NO.	PART #	DESCRIPTION	N15DCSS	N15DCIMSS	N20DCSS	N20DCIMSS
1	640985	BACK STOPPER	X	X	X	X
2	640986	TERMINAL BLOCK	X	X	X	X
3	640105	KIT SERVICE CONDENSER FAN COVER REPLACEMENT	X	X	X	X
4	640103	KIT SERVICE CONDENSER FAN REPLACEMENT	X	X	X	X
5	640178	CONTROL MODULE	X	X	X	X
6	640989	REAR DRIP TRAY	X	X	X	X